








WuWu

KOMODA 3SZ






P






P1








P2



























2x **10**




















PL: W celu ustabilizowana mebla występuje konieczność przykręcenia do ściany!!!

ANG: To ensure the stability of the furniture, it must be screwed to the wall !!!

DE: Zur Stabilisierung des Möbelstücks muss es an der Wand angeschraubt werden !!!

FR: Afin de stabiliser le meuble, il est nécessaire de le fixer au mur avec des vis.

